CBU-CEFLSW

Ceiling Flush Mount Passive Infra Red (PIR) Occupancy Detector & Photocell

CASAMBI Input: 100-240 Vac 50/60Hz

PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLING THE PRODUCT NOTE: CBU-CEFLSW is only compatible to work with Casambi enabled app.

This flush mounted CBU-CFFI SW is suitable for easy mounting through a 73/75mm diameter hole into a ceiling void which is at least 78mm deep. Configurable for any room occupancy style, via the free to download Casambi APP on Google Play or Apple APP Store.

INSTALLATION

To be installed by a competent person with reference to BS 7671 or equivalent local standards. If in doubt consult a qualified electrician.

- Plan where the CBU-CEFLSW is to be located (see diagram 1). Switch off supply and check for hidden cables and pipes. Make a 73/75mm diameter hole through a standard ceiling board.
- The CBU-CEFLSW should be connected as shown in diagram 2:
 - L Live in. N Neutral in. SW Switched line.
- · Ensure both springs are fitted to the moulding in the correct orientation (see diagram 3).
- Push the CBU-CEFLSW into the ceiling void, making reference to diagram 4.

OPERATION

To check the operation of the CBU-CEFLSW:

- Turn on the supply then after 20 seconds if the sensor has recognised movement of a person within its zone of detection the integral red LED on CBU-CEFLSW will stay illuminated for 4 seconds before the red LED turns off.
- Thereafter, every time movement is detected by CBU-CEFLSW the integral red LED will stay illuminated for 4 seconds.

The control also features adjustable time out (time lag) control and daylight threshold control which are configured by the Casambi APP.

PRECAUTIONS

- Do not place the CBU-CEFLSW near heat sources, fans or in ventilated ceiling voids.
- · Do not place close to, or positioned such that, any light source points directly into the CBU-CEFLSW.
- · Ensure wires and cables are securely held within the connection terminals.
- The CBU-CEFLSW should be protected by a 10 Ampere mcb or fuse.
- Disconnect the CBU-CEFLSW from the circuit before performing insulation testing of the wiring circuit.

TECHNICAL DETAILS

INPUT	
Voltage:	100 - 240Vac
Frequency:	50/60Hz
Max. mains current:	20mA
Standby current:	14mA
LOADING	
Fluorescent lamps, either high frequency or switch start	10 amps (2300W)
Incandescent or mains halogen lamps	10 amps (2300W)
Electronic or wire wound transformers.	6 amps (1500W)
LED lamps and drivers (PF \geq 0.95).	6 amps (1500W)
Compact fluorescent	6 amps (1500W)
Fans	1 amp (250W)
Inrush current	120A, 20mS
RADIO TRANSCEIVER	
Operating frequencies:	2.4 2,480 GHz
Max. output power:	+4 dBm
LUX PARAMETERS	
Range:	5 - 2000 lux
OPERATING CONDITIONS Note: The temperature difference between the detection target and the background must be at least 4 °C.	
	20 140 °C (lout

least 4 °C.	<u> </u>
Ambient temperature:	-20 +40 °C (lout 20mA)
Storage temperature:	-25 +75 °C
Max. relative humidity:	0 80%, non cond.
CONNECTORS	
Terminal block Wire size:	0.5mm ² - 2.5mm ² solid or stranded
Wire strip length:	6-7mm
Tightening torque:	0,4 Nm/4 Kgf.cm
MECHANICAL DATA	
Dimensions:	79mm x 85mm x 85mm
Weight:	97g (unpacked)
Degree of protection:	IP40

Built-in Class 2

Flame-retardant

Matt /White (RAL 9003)

polycarbonate

CONFORMITY AND STANDARDS

EMC emission:

EN 301 489-1 V2.2.0, EN 301 489-17 V3.1.1, EN 55032: 2015, EN61000-3-2: 2014, EN61000-3-3: 2013

EMC immunity: EN 301 489-1 V2.2.0 EN 301 489-17 V3.1.1

Environment:

Complies with WEEE and RoHS directives

5 YEAR WARRANTY

CBU-CEFLSW comes with a 5 year warranty from the date of manufacture and is CE marked.









Protection class:

Material (casing)

Finish / Colour



CBU-CEFLSW

Ceiling Flush Mount Passive Infra Red (PIR) Occupancy Detector & Photocell

Input: 100-240 Vac 50/60Hz

PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLING THE PRODUCT NOTE: CBU-CEFLSW is only compatible to work with Casambi enabled app











