# **CBU-CEFL10V**

# Ceiling Flush Mount Passive Infra Red (PIR) Occupancy Detector & Photocell

PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLING THE PRODUCT NOTE: CBU-CEFL10V is only compatible to work with Casambi enabled equipment.

This flush mounted CBU-CEFL10V is suitable for easy mounting through a 73/75mm diameter hole into a ceiling void which is at least 78mm deep. Configurable for any room occupancy style, via the free to download Casambi on Google Play or Apple APP Store.

#### INSTALLATION

To be installed by a competent person with reference to BS 7671 or equivalent local standards. If in doubt consult a qualified electrician

- Plan where the CBU-CEFL10V is to be located (see diagram 1). Switch off supply and check for hidden cables and pipes. Make a 73/75mm diameter hole through a standard ceiling board.
- The CBU-CEFL10V should be connected as shown in diagram 2:
  - L Live in. N Neutral in. +/- Control lines (polarity dependent)
- Ensure both springs are fitted to the moulding in the correct orientation (see diagram 3).
- Push the CBU-CEFL10V into the ceiling void, making reference to diagram 4.

## **OPERATION**

To check the operation of the CBU-CEFL10V:

- Turn on the supply then after 20 seconds if the sensor has recognised movement of a person within its zone of detection the integral red LED on CBU-CEFL10V will stay illuminated for 4 seconds before the red LED turns off.
- Thereafter, every time movement is detected by CBU-CEFL10V the integral red LED will stay illuminated for 4 seconds.

The control also features adjustable time out (time lag) control and daylight threshold control which are configured by the Casambi APP.

# **PRECAUTIONS**

- Do not place the CBU-CEFL10V near heat sources, fans or in ventilated ceiling voids.
- CBU-CEFL10V can be wired in parallel (sharing the same Live and Neutral).
- Do not place close to, or positioned such that, any light source points directly into the CBU-CEFL10V.
- Ensure wires and cables are securely held within the connection terminals.
- The CBU-CEFL10V should be protected by a 5 or 6 Ampere mcb or fuse.
- Disconnect the CBU-CEFL10V from the circuit before performing insulation testing of the wiring circuit.

#### 5 YEAR WARRANTY

CBU-CEFL10V comes with a 5 year warranty from the date of manufacture and is CE marked.





# TECHNICAL DETAILS

INPUT	
Voltage:	100 - 240Vac
Frequency:	50/60Hz
Max. mains current:	20mA
Standby current:	14mA
RADIO TRANSCEIVER	
Operating frequencies:	2.4 2,480 GHz
Max. output power:	+4 dBm
LUX PARAMETERS	
Range:	5 - 2000 lux

#### **OPERATING CONDITIONS**

Note: The temperature difference between the detection target and the background must be at least 4 °C.

Ambient temperature:	-20 +40 °C (lout 20mA)
Storage temperature:	-25 +75 °C
Max. relative humidity:	0 80%, non cond.

#### CONNECTORS

MEGUANUGAL DATA	
Tightening torque:	0,4 Nm/4 Kgf.cm
Wire strip length:	6-7mm
Terminal block Wire size:	0.5mm <sup>2</sup> - 2.5mm <sup>2</sup> solid or stranded
CONNECTORS	

#### MECHANICAL DATA

79mm x 85mm x 85mm
97g (unpacked)
IP40
Basic protection
Flame-retardant polycarbonate
Matt /White (RAL 9003)

#### CONFORMITY AND STANDARDS

# EMC emission:


EN 301 489-1 V2.2.0, EN 301 489-17 V3.1.1, EN 55032: 2015, EN61000-3-2: 2014, EN61000-3-3: 2013


## EMC immunity:


EN 301 489-1 V2.2.0, EN 301 489-17 V3.1.1


# **Environment:**


Complies with WEEE and RoHS directives











DANLERS Limited, Vincients Road, CHIPPENHAM, Wiltshire, SN14 6NQ, UK. Telephone: +44 (0)1249 443377 Fax: +44 (0)1249 443388 E-mail: sales@danlers.co.uk www.danlers.co.uk